



Headboard Installation

Attaching a headboard to a divan base is a simple process that can add a stylish and functional touch to your bedroom. If your divan base and headboard come with pre-drilled holes and struts, the process becomes even easier. In this guide, we'll go over step-by-step instructions on how to assemble your headboard and attach it to your divan base using the provided struts.

With these easy-to-follow instructions, you'll have your headboard securely attached to your divan base in no time, creating a comfortable and stylish bed for you to enjoy.

You will need:

- ▶ A divan base
- ▶ Screws
- ▶ Struts
- ▶ A headboard
- ▶ Screwdriver

1. Begin by unpacking the headboard, struts, screws, and screwdriver. Check to make sure you have all the necessary parts and hardware.
2. Attach the struts to either side of the back of the headboard. The struts should have pre-drilled holes that align with the holes on the headboard. Use the screws provided to attach the struts to the headboard. Tighten the screws securely, but not too tight as you may need to adjust them later.
3. Place the divan base in the desired location where you want your bed to be. Make sure it is level and stable.
4. Take your headboard and position it at the head of the divan base, with the bottom of the headboard aligned with the top of the mattress. Make sure the headboard is centred and flush against the base.
5. Align the pre-drilled holes on the struts with the corresponding holes on the divan base. The holes should be at the same height on both the struts and the divan base.
6. Insert a screw into one of the holes on one of the struts, ensuring it goes through both the strut and the divan base. Use your screwdriver to tighten the screw, but not too tight as you may need to adjust it later.
7. Repeat step 6 with the other hole on the same strut.
8. Repeat steps 6 and 7 for the other strut.
9. Once all screws have been inserted, use your screwdriver to tighten them fully.
10. Double-check to make sure that the headboard is securely attached to the divan base

And there you have it! Your headboard should now be firmly attached to your divan base and aligned with the top of the mattress. Enjoy your comfortable and stylish bed!



Out of Eden, Home Farm Buildings, Kirkby Stephen, Cumbria, CA17 4AP
sales@outofeden.co.uk
01768 372 939